



CAUTION:

Read, understand and follow ALL instructions before using this product

IMPORTANT SAFETY INSTRUCTIONS

- READ ALL INSTRUCTIONS CAREFULLY BEFORE USE. If you do not understand these instructions, need clarification or further explanation, please call our toll free answer line for assistance at 1-800-304-1316 Monday through Friday 8:00 a.m. until 5:00 p.m. CST.
- 2. Do not load Folding Platform Cart with more than 350 lbs. (175 kg).
- 3. Do not allow children to use unsupervised. This Folding Platform Cart is not a toy.
- 4. Always distribute payload evenly.
- 5. If any parts become damaged, broken or misplaced, do not use the Folding Platform Cart until replacement parts can be obtained.
- 6. Do not operate or use on objects that can cause damage to the tires.
- 7. SAVE THESE INSTRUCTIONS.

ASSEMBLY INSTRUCTIONS

Your Folding Platform Cart requires assembly. Account for all parts and hardware before beginning assembly. If any parts are missing, damaged, or if you have questions or need additional instructions, **DO NOT RETURN THIS PRODUCT TO THE RETAILER**, call the manufacturer at **1-800-304-1316**.

Tools required for assembly: 12 mm wrench or 12 mm socket driver

Refer to the exploded drawing and the parts list below during assembly.

STEP 1: Turn platform upside down. Use the cardboard from the carton to keep from scratching or damaging the finish.

STEP 2: Place the fixed casters nearest to the end of the platform with the handle. Attach the casters using the (4) 12mm bolts and lock washers included.

