



OWNER'S MANUAL

Model MH1980



- Important Safety Instructions
- Assembly Instructions
- Parts and Hardware Identification

Shelf Truck

CAUTION:

Read, understand and follow ALL instructions before using this product

Tricam International
7677 Equitable Drive
Minneapolis, MN 55344
www.black-cat-products.com
800-304-1316

IMPORTANT SAFETY INSTRUCTIONS

1. **READ ALL INSTRUCTIONS CAREFULLY BEFORE USE.** If you do not understand these instructions, need clarification or further explanation, please call our toll free answer line for assistance at **1-800-304-1316** Monday through Friday 8:00 a.m. until 5:00 p.m. CST.
2. Do not load Shelf Truck with more than 500 lbs.
3. Do not allow children to use unsupervised. This Shelf Truck is not a toy.
4. Always distribute payload evenly.
5. If any parts become damaged, broken or misplaced, do not use the Shelf Truck until replacement parts can be obtained.
6. Do not operate or use on objects that can cause damage to the casters.
7. **SAVE THESE INSTRUCTIONS.**

ASSEMBLY INSTRUCTIONS

Your Shelf Truck requires assembly. Account for all parts and hardware before beginning assembly. If any parts are missing, damaged, or if you have questions or need additional instructions, **DO NOT RETURN THIS PRODUCT TO THE RETAILER**, call the manufacturer at **1-800-304-1316**.

Refer to the exploded drawing and the parts list on the following pages during assembly.

Step 1 Turn base frame upside down, using the cardboard from the carton to keep from scratching or damaging the finish.

Step 2 Attach the casters to the bottom side of the base frame using the (16) 20mm bolts, washers, lock washers, and nuts provided.

Step 3 Turn the cart upright onto its casters. Insert the wood base board into the base frame.

Step 4 Insert an end frame into the end of the base frame. Secure with (2) 25mm bolts and washers provided. Repeat this process for the other end frame.

Step 5 Install the wood shelves at the desired heights.

PARTS AND HARDWARE IDENTIFICATION

Parts

- 1) Base frame - (1)
- 2) Base board - (1)
- 3) Wood shelf - (2)
- 4) End frame - (2)
- 5) Swivel caster - (2)
- 6) Fixed caster - (2)
- 7) 20mm bolt - (16)
- 8) Washer - (16)
- 9) Lock washer - (16)
- 10) Nut - (16)
- 11) 25mm bolt - (4)
- 12) Washer - (4)

